

### **Specification:**

1. Determination method: high frequency electromagnetic wave induction type
2. Measuring range: 0 to 100%
3. Resolution: 0.1%
4. Display: LCD digital display
5. Scanning depth: 50mm
6. Tree species Fixed: 10 stalls
7. Power supply: one 9v battery
8. Size: 160 × 60 × 27 (mm)
9. Weight: about 200g

### **Features:**

1. Technical support: the use of advanced sensors.
2. Measuring range: suitable for crude wood, dry plank stuff, a variety of timber products, the measurement range of 0 to 100%.
3. Smart light: weighs 200 grams, about 160mm, small size, easy to carry, suitable for onsite use.
4. Non-destructive testing: the abolition of probe insert, just lightly touch the probe measured surface, which can display the current moisture content of wood, and will not damage the test object.
5. Intuitive and convenient: To determine the depth of 50mm and directly with digital display.
6. Simple and quick: Set up trees corrected, to ensure that the moisture content of the various species accurate determination.
7. Integrated structure: the probe and the body became one, avoiding the fault caused by the cables.

### **Payment Methods:**

We accept TT bank wire transfer, Western Union, Paypal and escrow payment offered by Alipay Escrow and Escrow.com.

For latter three payment methods, extra charges shall be applied.

### **Shipping Methods:**

To be shipped by express mail, by air or by sea based on customer's request and weight/volume of goods.

### **Warranty:**

We provide a limited quality warranty of 12 months for the items sold dating from their delivery date.

[Meter8](#) is your best choice !