

Front panel descriptions:

1. Probe shield
2. Measure probe
3. Power button
4. Date-hold button
5. LCD display
6. Battery cover

Measuring method:

- A. Press "POWER" button and turn on power, then display "01 or 02".
 - B. Take off probe shield and press the pins of two sides with fingers. The instrument is work normally and can measure object if the display value is approx. 30%.
- C. Insert the pins into the object approx. 5mm, which display the containing water of the object.
 - D. Press "HOLD" button then can hold current value, which display "H", press "HOLD" again, which can cancel hold function.
- E. After measuring, press "POWER" button, turn of power and cover probe shield, then measuring is over.