

MD917 Portable Automatic Concrete Wall Moisture Meter

This is a precision instrument adopting HF electromagnetic waves to measure the moisture content ratio without damaging the object under test. It can be set depending on different building material to raise its measurement accuracy.

Performance characteristics

- * Measurement through HF electromagnetic sensing
- * 10 different at option
- * Automatic temperature compensation
- * Setting of upper limit of moisture content ratio, prompting of overrunning
- * Ultra-large LCD ensuring clear readings
- * Automatic prompting of low voltage

Main Parameter

Range of measurement: 0~40%

Accuracy: $\pm(1\% \pm 1)$

Resolution: 0.5%

Environment:

temperature: 5°C~40°C

Humidity: 0~80%Rh

Power supply: 3×1.5V AAA battery

Weight: 95 g(not including battery)

Size: 132×67×26mm