

Digital Multifunctional Moisture Meter TK100

The Moisture Meter TK100 is a high-tech testing instrument in our company. The newly designed moisture meter with extensive probes suits to many materials moisture content testing, just as grains, chemical raw material, plastic granule, soap powder, soil, Chinese traditional medicine and other fibre materials.

The moisture meter TK100 utilizes the relationship between moisture content and electrical resistance to effectively measure the moisture content quickly and accurately.

Specification

1. Display: 4 digital LCD
2. Measuring range : 0-84%
3. Temperature: -10-60C
4. Humidity: 0%-90%
5. Resolution: 0.1
6. Accuracy: $\pm 0.5\%$
7. Operation: Electrical Resistance Method, Automatic temperature Compensation
8. Power supply: 4x1.5 AAA size (UM-4) battery
9. Dimensions:
460mm×75mm×35mm
- Weight: 203g (not including batteries)
10. Guarantee: 1 year
11. Certification : CE