

The Cotton Moisture Meter is a valuable tool in examining cotton collection, processing when buying or selling cotton. The TK100C utilizes the relationship between moisture content and electrical resistance, the moisture content of cotton, cotton seed and lint quickly to measure effectively and accurately.

Specification

- * Display: 4 digital LCD
- * Measuring range: 7% -40%
- * Temperature: 0-60
- * Humidity: 5% -90%
- * Resolution: 0.1
- * Accuracy: $\pm 0.5\%$ n
- * Operation: Electrical Resistance Method, Automatic temperature compensation
- * Power supply: 4x1.5 AAA (UM-4) battery
- * Dimensions:
460mm × 75mm × 35mm
- * Weight: 203g (without batteries)
- * Certification: CE