

The Moisture Meter TK100S is a high-tech testing instrument in our company. The newly designed moisture meter with extensive probes suits to many materials moisture content testing.

1. Features:

1.1.It is portable, compact, easy to use and the moisture measurement readings are instant.

1.2.Digital display with back light gives exact and clearly reading although you stay at the somber conditions.

1.3.It will save time and expense by monitoring dryness and helps to prevent deterioration and decay caused by moisture whilst in storage, therefore processing will be more convenient and efficient.

1.4.The moisture meter operates by electrical resistance and has automatic temperature compensation.

1.5.Measurements are taken by inserting the sensors into the bale of materials.

1.6.Manual off at any time .Auto power off after 5 minutes from last operation.

## **Specification**

Display:4 digital LCD

Measuring range :5-30%

Temperature:0-60

Humidity:5%-90%

Resolution:0.1

Accuracy:  $\pm 0.5\%$

Operation: Electrical Resistance Method, Automatic temperature Compensation

Power supply: 4x1.5 AAA size (UM-4) battery

Dimensions:

460mm×75mm×35mm

Weight:203g (not including batteries)

Guarantee:1 year

Grains:5 kinds(**Corn,wheat,rice,bean,wheat flour.**)

Packing: color box packing