

Tobacco moisture meter TK100T

The Tobacco Moisture Meter is a valuable testing instrument during the Tobacco collection, processing and when buying or selling. The newly designed TK100T utilizes the relationship between moisture content and electrical resistance to effectively measure the moisture content of tobacco quickly and accurately.

Specification

1. Display: 4 digital LCD
2. Measuring range : 8%-40%
3. Temperature: 0-60
4. Humidity: 5%-90%
5. Resolution: 0.1
6. Accuracy: $\pm 0.5\%$
7. Operation: Electrical Resistance Method, Automatic temperature Compensation
8. Power supply: 4x1.5 AAA size (UM-4) battery
9. Dimensions: 460mm×75mm×35mm
10. Weight: 203g (not including batteries)
11. Guarantee: 1 year
12. Certification : CE